


Instruction Manual

PIE & FOOD WARMERS



40DT

Version 4

80DT

Version 5

83DT

Version 5

CONTENTS

Product Features	2
Specifications	2
Parts Included	2
Safety Instructions	2
Cleaning & Maintenance	3
Installation	3
Operation	3
Troubleshooting	4
Spare Parts	5
Circuit Diagram	5
Warranty	7

PRODUCT FEATURES

- Stylish brushed stainless design
- Precise thermostat control
- Easily removable shelves, drawers and crumb tray for easy cleaning
- Double skin cavity for even temperature and low running costs
- Thermometer

SPECIFICATIONS

Model	Power (230V)	Size (mm)			Kg
		W	D	H	
40DT	1250W	505	320	360	20
80DT	1250W	585	350	485	30
83DT	1250W	585	350	485	22

*Specifications subject to change

PARTS INCLUDED

- Pie & Food Warmer (appropriate model) – includes shelves or drawers (model dependent)
- Crumb Tray

- Instruction Manual

Any damage to the appliance as a result of freight must be reported to the freight company and to the agent responsible for the despatch of the appliance within 24 hours of receipt. No claims will be accepted after this period.

SAFETY INSTRUCTIONS

Read all Instructions and safety warnings prior to use. Keep user manual for future reference.

Service and repair should only be performed by qualified technicians who have read and understand this manual.

Personnel must be trained prior to operating this appliance.

This product is suitable for commercial use only.

This appliance should not be operated by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the safe use of the appliance by a person responsible for their safety.

Keep out of reach from children.

Avoid contact with the exterior of this appliance as surfaces can get hot.

Do not position appliances where hot surfaces may be accidentally touched.

The appliance should be disconnected from all power and allowed to cool before cleaning or servicing.

Regularly inspect the electrical supply cord and plug and discontinue use immediately if damage is found. Return to manufacturer or authorised repairer for repair prior to use.

This appliance contains no user-serviceable parts. Roband Australia, one of our agents, or a similarly qualified person(s) should carry out repairs.

Keep cord away from heated surfaces.

This appliance is intended as a food display warmer only. It should not be used to cook food.

Do not remove any cover panels from the appliance.

Roband will accept no liability if:

- Non-authorized personnel have tampered with the appliance
- The instructions in this manual have not been followed
- Non-original spare parts are used
- There is any damage to the unit

CLEANING & MAINTENANCE

CAUTION: Disconnect from power and allow to cool before cleaning.

CAUTION: Steel cutting processes used in the construction of this appliance can result in sharp edges. Avoid contact with sharp edges during cleaning and maintenance.

Do not clean with the use of a water jet or immerse in water.

Do not use caustic or abrasive cleaning products as they will damage the appliance.

Wipe all surfaces of the appliance with warm soapy water using a damp non-abrasive cloth.

Empty crumb tray on a daily basis and wipe with a damp cloth with warm soapy water.

Regular cleaning will prevent a build-up of oils and keep the appliance looking new.

INSTALLATION

Remove all packaging materials, tape, and any protective plastic from the appliance. Remove

any glue residue from the protective plastic or tape using citrus cleaner.


Place the product on a firm, level surface in the desired position. Install at least 100mm from combustible materials and a least 50mm from any other appliance.

Do not connect to power using an extension cord.


Before connecting the appliance to the power supply, ensure that all switches are in the OFF position. Connect only to a RCD protected, grounded 3-pin outlet.

OPERATION

1. Turn on/off switch to the ON position. The switch will illuminate to indicate the unit is powered.



Set the thermostat knob to the desired temperature.



2. Pie warmer should be pre-heated for 20 minutes before loading food.

PIE LOADING

When loading product into the pie warmer take note that the lower shelves will heat up more quickly due to proximity to the element.

Therefore use lower shelves if partially filled.

Additionally, if unit is completely filled, products such as pies that take longer to heat up should be placed on the lower shelves.

Using foil on a shelf may block heat to the shelves above it. If foil is used ventilation holes must be made every few centimetres.

The unit is designed as a food warmer for use with freshly baked or pre-cooked product.

If frozen products are used they must be pre-heated before being put in the Pie Warmer.

(residual current devices) tripping, particularly when the appliance is not used for an extended period, or stored in humid conditions.

Regular use can avoid moisture absorption.

TROUBLESHOOTING

If the Pie Warmer does not function check the following points before calling for service.

- ✓ The appliance is plugged in correctly and the power switched on.
- ✓ The power point is not faulty.
- ✓ The on/off switch is not in the OFF position.
- ✓ The thermostat is not set to OFF.
- ✓ The thermostat and on/off switch knob are not loose or broken, rendering the switches inoperable.
- ✓ If appliance is tripping RCD, this may be caused by:
 1. Too many appliances on the same circuit (relocate appliance to another circuit and try again);
 2. Faulty appliance; or
 3. Moisture absorption into heating element.

Tubular heating elements are subject to moisture absorption which can result in RCDs

SPARE PARTS

Common

EC0179	On/Off Switch
EC0642	Plug & Cord - 10A
ES0264	Pilot Light - Amber (incl. Nut)
HC0043	1250W Element
MC1243	Thermometer
MS0583	Knob
PC0008	Silicone Bumper
PC0060	Cord Clamp - 10A
TS0029	Thermostat and Knob

40DT

PS0023	Knob (incl. Screw and Washer)
SS0013	Drawer Assembly
SS0239	Crumb Tray


80DT

PS0024	Handle Kit (incl. Screw and Washer)
SS0014	Drawer Assembly
SS0123	Crumb Tray

83DT

MC1793	Rack
PS0021	Knob (incl. Screw and Washer)
SS0123	Crumb Tray
SS0251	Door

CIRCUIT DIAGRAM



NOTES

WARRANTY

The warranty conditions set out below are in addition to any warranties implied or governed by law.

Roband Australia warrants that this appliance shall be delivered free from defects in material and workmanship. The warranty for this product is offered to the original purchaser, to be free of fault in both workmanship and materials for a period of 12 months from date of purchase. Roband's obligations pursuant to this warranty are limited to the repair or replacement of the defective goods or materials, at its discretion and subject to the terms contained within this Warranty statement.

The following conditions apply:

The product must be installed, maintained and used under normal operating conditions within the scope of the operating instructions.

All warranty claims must be submitted to Roband or an authorised Roband dealer, and Roband authorisation must be granted prior to repairs being carried out. Proof of purchase is required for any repair authorisation.

Warranty is back to base, meaning delivery to and collection of your product to Roband or an authorized service agent is the responsibility of the purchaser.

Where a product cannot be returned back to base, on-site warranty can be arranged by prior agreement.

The following exclusions apply:

Claims or faults arising from misuse, neglect, transport damage or other mechanical damage, including but not limited to; door's, hinges & interlock switches etc., other than those arising from manufacture or material defects. Where relevant, glass, Teflon® and lamps are not included in this warranty and RCD tripping due to moisture absorption by Tubular Heating Elements is not a warranty fault.

Roband or any subsidiary company or Agent shall not be liable for loss of profit or damage to other equipment and property except where it is in breach of the guarantees provided in accordance with applicable legislation.

Roband reserves the right to reject a warranty claim if it is not satisfied with the circumstances under which the fault occurred or where a product has been altered from its original specification.

For on-site repairs outside of capital city metropolitan areas, travel costs, service callout fee and related labour costs etc. are the responsibility of the claimant.

Any costs incurred for false claims or faults due to incorrect usage etc. are the responsibility of the claimant.

Any attempt to repair the product by non-Roband approved service personnel or the use of non-genuine parts will void the warranty agreement

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For the name of your nearest Australian authorised service agent, please contact:

Roband Australia Pty Ltd
1 Inman Road,
Cromer, NSW, 2099, Australia
Warranty: 1800 268 848
Tel: +61 2 9971 1788
Email: sales@roband.com.au
Web: www.roband.com.au

For your nearest International distributor,
please visit:
<https://www.roband.com.au/worldwide/>



© Copyright 2021 – Roband® Australia Pty Ltd

All rights reserved. No part of this work may be reproduced or copied in any form or by any means, electronic or mechanical, including photocopying or posting to a website, without the written permission of the publisher. The material contained within this document is intended entirely for instructional Purposes. Roband® Australia is a wholly Australian owned company and has been manufacturing quality commercial catering equipment for the food service industry for more than 60 years.

26/05/2023