

FEATURES & OPTIONS FOR ALL GRILL STATIONS

Retainer Clip & Grill Sheet[^]

These are used to keep the Grill Station plates clean during use. They are easily removed for washing. The sheet is also non-stick preventing the food from sticking to the plates. **IDEAL FOR HIGH PRODUCTIVITY AND FAST CLEANING.**

Side Draining Grease Channel

This is designed to handle high volume of grease from cooked food. The Grease Channel drains into a collection vessel such as a small steam table pan. (*Only available for Manual timer models).

Rear Stand

The Rear Stand is designed to raise the Grill Station rear so that grease and crumbs drain & collect in the forward positioned grease box.

Plate Spacer

Various sizes are available and these are designed to ensure a consistent height is maintained between the top and bottom plates during operation. These are ideally suited to preparation of delicate products such as croissants.

Aluminium Grill Pattern Plates

Designed to sit between the Grill Station smooth plates and Grill Sheet with Clip, the Aluminium Grill Pattern Plates produce a crosshatched char grill style pattern on the food being produced.

Rear Stand




RS830 Rear Stand




GSA810S sitting on a Rear Stand RS830

Optional removable Grill Sheet with Retainer Clip (Standard on Electronic timer models)



Aluminium Grill Pattern Plate (for smooth plate Grill Stations only)




GS6-P1 set of 2 Aluminium Grill Pattern plates to suit 6 slice Grill Stations



Toasted food showing the pattern result



Showing easy installation on a Grill Station top plate



Showing easy installation on a Grill Station bottom plate

[^]This item is excluded from the official Australian Made and Owned certification.

Grill Stations cont'd


FEATURES & OPTIONS FOR ALL GRILL STATIONS

Side Draining Grease Channel



Side Draining Grease Channel
on 8 slice Grill Station (pan not included)
Only available for the Manual Timer models.

Spacers available in various sizes to suit



GSPS835 Spacer










GSPS845 Spacer inside a GSA810S

Spatula[^]



Premium spatula pictured

ACCESSORIES

GRILL STATION ACCESSORY		MODEL TO SUIT 6 SLICE GRILL STATIONS	MODEL TO SUIT 8 SLICE GRILL STATIONS
	Sheet Retainer Clip	RC6	RC8
	Grill Sheet [^] (PTFE) (non-stick)	PGS605 [^] (5 pack QTY) PGS610 [^] (10 pack QTY)	PGS805 [^] (5 pack QTY) PGS810 [^] (10 pack QTY)
	Side Draining Grease Channel (Only available for the Manual Timer models.)	GC6	GC8
	Premium Spatula [^]	SP12 [^] (12 pack)	SP12 [^] (12 pack)
	Rear Stand	RS630	RS830
	Plate Spacer	GSPS625 GSPS635 GSPS645	GSPS825 GSPS835 GSPS845
	Aluminium Grill Pattern Plate (suits smooth plate Grill Stations only)	GS6-P1 (a set of 2)	GS8-P1 (a set of 2)

[^]These items are excluded from the official Australian Made and Owned certification.